




PowerPrompter Flip Screen Instructions for Windows Vista/7.

Close all applications.

Right click on an empty area of the desktop and select “Screen Resolution”




On the screen resolution screen, click “connect a projector” and select “extend”.




This will enable the projector monitor as an extension of your desktop and a second monitor.

Back on the Screen Resolution screen, click on Resolution and change it to 800x600 for both monitors, then click OK.


When prompted, click “Keep Changes”.




To set the windows environment for best performance, Click the Windows Start button and select “Computer” from the menu.




At the top of the computer window, click "System Properties".




Click "Performance Information and tools" in the lower left corner of the System Properties screen.



In the Performance screen, click “Adjust visual effects” in the upper left corner.



In the Performance Options screen, click adjust for best performance and click OK.



You are now configured for optimal performance for the PowerPrompter software flip.

Open the PowerPrompter software.

From the file menu, select “Secondary Monitor”, then either “Mirror” or “Inverted Mirror” depending on your specific monitor configuration. Mirror is the most common.

